


Debut Carbon Setup Guide

Please read before unpacking

Getting started:

- Make sure to have enough space to unpack your turntable.
- Always unpack and setup in a clean environment.
- Important for warranty: Do not throw packaging away.
- Setup is demonstrated with Debut Carbon Esprit SB.

1 Unpack all items from accessory bag.



- a) Adapter for 7" singles
- b) Anti Skating Weight
- c) Connect it E RCA cable
- d) Round belt for 78 RPM (not incl. with Debut Carbon DC)
- e) Standard flat belt for 33/45 RPM

2 Remove dust cover carton from the box.



3 Lift the wrapped turntable out of the box.



4 Carefully remove the protection covering.



5 Unpack the counterweight.



6 Unpack the power supply.



7 Unpack the platter.



9 Speed Change

- A** Debut Carbon
- OR-
- B** Debut Carbon Esprit SB
- Debut Carbon RecordMaster HiRes

10 Put the drive belt on the pulley and sub-platter.



10 Put the drive belt on the pulley and sub-platter.




11 Put the platter on the turntable.



12 Remove tonearm twist tie.



13 Put the counterweight in place.



14 Remove the needle protection cover.




15 Put a record on the platter.



16 Place the tonearm between platter and armrest.



17 Balance the tonearm so it stays level by turning the counterweight forwards and backwards on the rod.



18 Turn the front dial of the counterweight (not the whole weight) so the '0' is in line with marker at the back of the tonearm.



19 Turn the whole counterweight counter-clockwise until the scale reads 18.




20 Put the loop of the Anti Skating Weight in the second groove on the tonearm post.



21 Unpack Dust Cover and put it on the turntable.



22 Connect to your hifi-system and enjoy your music!



Find possible sets on the backside of this paper.

Debut Carbon

Connect to any amp with integrated phono amplifier or use an external phono preamp.

Features



Gold-plated
RCA sockets




Carbon
Tonearm



Included
felt mat

Possible Setup:

Pro-Ject Speaker Box 5 S2 (bookshelf speaker)
and Pro-Ject MaiA S2 (stereo integrated amplifier).



Debut Carbon Esprit SB

Connect to any amp with integrated phono amplifier or use an external phono preamp.

Features



Gold-plated
RCA sockets



Carbon
Tonearm




Acrylic
Platter



Electronic
Speed Control

Possible Setup:

Pro-Ject Speaker Box 5 S2 (bookshelf speaker)
and Pro-Ject MaiA S2 (stereo integrated amplifier).



Debut Carbon RecordMaster HiRes

Output Board: Record Level potentiometer, Input Switch, Line Out, USB Out, Optical Out. You can record your vinyl in high resolution formats.

Features



Output
Board



Carbon
Tonearm



Acrylic
Platter



Electronic
Speed Control

Possible Setup:

Pro-Ject Speaker Box 5 S2 (bookshelf speaker)
and Pro-Ject MaiA S2 (stereo integrated amplifier).

